

ARCHI

ISO 9001 ISO 14001



KROST.

krost.com.au

1800 1KROST



OPERATING INSTRUCTIONS

SEAT HEIGHT

Lift middle lever on right

BACK ANGLE

Push inner lever on left up to unlock. Push down to lock in position. For front tilting control, when back is unlocked, lean back, push outer lever on left up until it clicks to engage front tilt. Lean back, push outer lever on left down until it clicks to disengage front tilt

SEAT SLIDE

Turn back knob on right

TENSION CONTROL

Turn front knob on right clockwise to increase tension, turn anti-clockwise to decrease tension

ARM HEIGHT

Pull trigger on side of arms and push down/up

ARM WIDTH

Pull/push arms in or out sideways

ARM ANGLE AND DEPTH CONTROL

Push armrests forward, back and twist into position

CARE INSTRUCTIONS



MESH

Rub in a circular motion with soapy water. Wipe with a damp cloth.



FABRIC

Vacuum regularly and brush with a soft bristled brush.