

KAY

ISO 9001 ISO 14001



5 YEAR
WARRANTY



KROST.

krost.com.au

1800 1KROST



OPERATING INSTRUCTIONS

SEAT HEIGHT

Push right hand control lever forward

SEAT AND BACK ANGLE

Push left control lever forward to unlock seat and back recline,
push lever back to lock seat and back in upright position

CARE INSTRUCTIONS



MESH

Rub in a circular motion with soapy water.
Wipe with a damp cloth.



FABRIC

Vacuum regularly and brush with a soft
bristled brush