

# SONIC TASK

ISO 9001 ISO 14001



KROST.

---

krost.com.au  
1800 1KROST



## OPERATING INSTRUCTIONS

### SEAT HEIGHT

Lift lever on right

### BACK ANGLE

Pull out lever on right. Push in to lock

### TENSION CONTROL

To increase tension turn knob at base of the chair clockwise and to decrease, turn anti-clockwise

### ARM HEIGHT

Push button on side of arm. Release to lock

## CARE INSTRUCTIONS



### MESH

Rub in a circular motion with soapy water.  
Wipe with a damp cloth.



### FABRIC

Vacuum regularly and brush with a soft  
bristled brush.